



线号+颜色	元件名称
1	IGNITION COIL SWITCH
2	STOP SW
3	STARTER SIGNAL SWITCH
4	TAIL LIGHT SIGNAL SW L
5	TAIL LIGHT SIGNAL SW R
6	START MOTOR HEATING
7	FUEL PUMP RELAY SIGNAL
8	
9	
10	IGNITION POWER
11	CAN L
12	SPEED SIGNAL
13	
14	ENGINE TEMPERATURE SIGNAL
15	WATER SENSOR SIGNAL
17	CAN R
18	WCI B-
19	PROXIMITY SIGNAL LOW
20	IGNITION SIGNAL
21	IGNITION SIGNAL SW L
22	IGNITION SIGNAL SW R
23	STOP SW
24	STARTER SIGNAL SW
25	FUEL INJECTOR SIGNAL
26	COOLANT SENSOR VALVE
27	FUEL INJECTOR
28	STOP SW
29	WATER-LEVEL SENSOR SIGNAL
30	FUEL SIGNAL SW
31	WATER PRESSURE SIGNAL
32	TEMPERATURE SIGNAL
33	ENGINE TEMPERATURE SIGNAL
34	CAN L

NOTE OF COLOR	
RD	RED
YL	YELLOW
BL	BLUE
PK	PURPLE
BLK	BLACK
WH	WHITE
GR	GREEN
OR	ORANGE
SW	STEEL
LT	LIGHT

MODEL: EXPLORER 300 E5

浙江创台车业有限公司
TR300T 款五大灯常亮
电气原理图
TR300T-4-DWYL