



ECU接口编号	ECU Function
1	OXYGEN SENSOR HEATING IDEL
2	STEPPER MOTOR SIGNAL A
3	SPEED SIGNAL
4	12V B+
5	TRIGGER SIGNAL HIGH
6	TRIGGER SIGNAL LOW
7	B-
8	INTAKE PRESSURE SIGNAL
9	ENGINE RPM SIGNAL
10	B-
11	IGNITION COIL DRIVE FUEL
12	INJECTOR SIGNAL
13	IDEL STEPPER MOTOR SIGNAL D
14	
15	5V B+
16	CAN L
17	CAN H
18	FAULT CODE LIGHT
19	
20	OXYGEN SENSOR SIGNAL
21	THROTTLE POSITION SIGNAL
22	
23	
24	IDEL STEPPER MOTOR SIGNAL C
25	IDEL STEPPER MOTOR SIGNAL B
26	IGNITION POWER
27	5V B-
28	FUEL PUMP RELAY SIGNAL
29	MAIN RELAY SIGNAL
30	
31	START/STOP SIGNAL
32	ENGINE TEMPERATURE SIGNAL
33	INTAKE TEMPERATURE SIGNAL

NOTE OF COLOR	
RD	RED
YE	YELLOW
BU	BLUE
PL	PURPLE
BK	BLACK
WH	WHITE
PK	PINK
GY	GREY
BN	BROWN
OR	ORANGE
GN	GREEN
LT	LIGHT
DK	DARK

備、通用件登記
 描 校
 旧底图总号
 底图总号
 签 字
 日 期

T10-KS150E5				浙江创台车业有限公司			
T10-KS150-DQYL				电气原理图			
标记	数量	更改文件号	签字	日期	图样	标记	特性
设计			标准化		S		重量
校对			审定				比例
审核							
工艺			日期				
共 1 页				第 1 页			